

# Flow Monitoring

By: Angus Leger

King County Department of Natural Resources and Parks  
Wastewater Treatment Division  
Seattle, Washington

# *Why* do we monitor wastewater flow?

- Plan wisely for future expansion.
- Direct maintenance and repair.
- Supply modeling projects with vital information .
- Accurately document overflows.
- Help pinpoint I/I sources.
- To understand our system better in general.

## *How do we monitor wastewater flow?*

- Here at WTD we use an array of different sensor technology to measure depth and velocity. With depth and velocity values flow is calculated.
- Permanent Flow Meters (i.e. cso sites)
  - Hydro Ranger (large range) and others
- Temporary and Long-Term Meters
  - Over 100 portable flow meters are currently active


# Portable Flow Meters

- Marsh McBirney
  - Flo-ToteII, Flo-Tote III, and Flo-Dar systems.
- ADS
  - 3600/01 and Flow Shark systems.

# Marsh McBirney Flo-Dar System



- Flo-Dar shooting up-stream



- All sensors in one nice package
- \* : Pressure depth sensor kick in during once unit is submerged along with electromagnetic velocity sensor.

# The Nitty Gritty: Installation / Maintenance



- Marsh McBirney Flow Tote III system with tension ring install.
- “Rags” disrupting electromagnetic velocity sensor. Please remove.

- Matt Charles knows that safety is number one when it comes to maintenance.



# The Data Analysis Process

1. Retrieval
2. Review
3. Adjustment
4. Finalization

# Data Review

- Depth and Velocity
- Site Visit Log, Rain Events, and Photo Library
- Setup Changes

# Depth and Velocity

- Is the data continuous and as it “should” be?
- Do they match up? If not, does it still make sense (is it real data)?
- Is there a diurnal pattern? Is there a seasonal pattern?
- Does the average range of the data change?



W

ain  
w Data  
art  
xt Reports

ions


ort Settings


ject Data Span  
1/2004 10:56 AM  
1/2007 12:26 PM  
Custom Data Span

art Length  
Week  
ca Average  
5 Minute

mes

Level (in)  
Velocity (fps)  
Flow (mgd)  
Main Battery (vdc)  
Surcharge Level (in)







W

ain  
w Data  
art  
xt Reports

ions


ort Settings

ject Data Span  
/2004 10:00 AM  
2/2007 11:00 AM  
Custom Data Span

art Length  
Day  
ca Average  
5 Minute

mes

Level (in)  
Velocity (fps)  
Flow (mgd)  
Main Battery (vdc)  
Surcharge Level (in)



[Main](#)  
[Raw Data](#)  
[Chart](#)  
[Text Reports](#)

[Options](#)  
[Report Settings](#)  
 Project Data Span  
 5/2004 11:05 AM  
 5/2007 12:05 PM  
 Custom Data Span


Chart Length  
 Week  
 Data Average  
 5 Minute

[Names](#)  
[Level \(in\)](#)  
[Velocity \(fps\)](#)  
[Flow \(mgd\)](#)  
[Main Battery \(vdc\)](#)  
[Surcharge Level \(in\)](#)




### kenmoremh54

Level (in)    Velocity (fps)    Flow (mgd)    Main Battery (vdc)  
 Surcharge Level (in)



# Site Visit Log, Rain Events, and Photo Library

- Detailed record of what the crew members did.
- Tools to cross reference.
- May list changes in site setup and multiplier/site coefficient.
- Help explain gaps, pattern changes, and poor quality data.
- Confirm a spike in the data.
- Help identify I/I problems.






Navigation menu:

- Home
- Main
- Raw Data
- Chart
- Text Reports
- Options
- Report Settings
- Project Data Span: 9/2004 10:30 AM to 2/2007 11:15 AM
- Custom Data Span
- Chart Length: Month
- Data Average: 5 Minute
- Names
  - Level (in)
  - Velocity (fps)
  - Flow (mgd)
  - Main Battery (vdc)

Charting tools: Pan, Zoom In, Zoom Out, Pan, Auto Scale, Line, Bar, Pie, Scatter.





# Setup Changes

- Changes in the site setup can drastically change the data.
- Check for changes in each data file setup before appending to see if it is the same as the original setup of the FloWare project.



W

ain  
w Data  
art  
xt Reports

ions


ort Settings

ject Data Span  
7/2006 12:50 PM  
/2007 9:50 AM  
Custom Data Span

art Length  
Week  
ca Average  
5 Minute

mes

Level (in)  
Velocity (fps)  
Flow (mgd)  
Main Battery (vdc)  
Surcharge Level (in)







W

ain  
w Data  
art  
xt Reports

ions

port Settings

ject Data Span  
7/2006 12:50 PM  
/2007 9:50 AM

Custom Data Span  
7/2006 12:50 PM  
0/2006 9:50 AM

art Length


Week

ca Average

5 Minute

mes

Level (in)  
Velocity (fps)  
Flow (mgd)  
Main Battery (vdc)  
Surcharge Level (in)





ain  
w Data  
art  
xt Reports

ions

ort Settings

ject Data Span  
7/2006 12:50 PM  
/2007 9:50 AM

Custom Data Span  
0/2006 12:50 PM  
/2007 9:50 AM

art Length

Week

ca Average

5 Minute

mes

Level (in)

Velocity (fps)

Flow (mgd)


Main Battery (vdc)

Surcharge Level (in)



esi14mh73

● Level vs Velocity





W

ain  
w Data  
art  
xt Reports

ions


ort Settings

ject Data Span  
7/2006 12:50 PM  
/2007 9:50 AM  
Custom Data Span

art Length  
Week  
ca Average  
5 Minute

mes

Level (in)  
Velocity (fps)  
Flow (mgd)  
Main Battery (vdc)  
Surcharge Level (in)



# Documentation

- It is important to take notes during detective work. A very important clue may be lost if the data review process is done without attention to detail.

# Shout Outs

- Thank you Sarah White and Lisa Taylor for the warm welcome.
- Special thanks to the flow monitoring team: Abraham Araya, Janice Johnson, Lee Miller, Mike Sands, and John Gemmill. You guys have taught me a lot and have been a blast to work with.
- My cube-mate Alyssa Benson and the rest of the GIS crew for adopting me into their little nucleus. West Wing!
- Much props to the DNRP/WTD Summer Interns of 2007. **It has been a privilege and an honor to be part of the greatest group of interns ever assembled.** Good Luck in all of your future endeavors.